




Plate Storage Horns Fast Removing (Pair)

FITTING INSTRUCTIONS

VER-PSH-003



QUANTITY	MOUNTING	FITS
Pair (2 Horns)	Quick-Release Pin	VERVE Racks & Rigs

Need help? Contact support@vervefitness.com or visit vervefitness.com/support
vervefitness.com

Before You Begin.

The Plate Storage Horns — Fast Removing ship as two pre-assembled units. Each horn, its mounting bracket and its quick-release pin are welded and finished as one piece — there is no hardware to bolt together. This is a **rack attachment**: it mounts onto the existing hole pattern of a VERVE rack or rig upright you already own. This guide covers fitting the pair and using them safely once fitted.

Tools required.

None. Each horn fits and releases using its built-in quick-release pin — no spanners, sockets or fasteners are needed.

SAFETY INFORMATION

Before loading either horn, confirm its quick-release pin is fully through the upright and the bracket sits flush and square against the upright face.

Load plates evenly across both horns — don't stack all your plates on one side while the other sits empty.

A loaded horn cantilevers its full load off the upright, so re-check the pin engagement before every session and any time a horn has been removed and refitted.

Only fit these horns to a rack or rig that is itself correctly assembled, anchored and on flat, stable ground.

Keep fingers clear of the pin mechanism while fitting or removing a horn.

This attachment must be fitted by adults only.

FITTING TIPS

The mounting bracket is designed for VERVE racks and rigs. If fitting to other equipment, check the upright's hole spacing and profile against the bracket before use.

Each horn fits independently — set both at the same height for a level pair, or at different heights to separate plate sizes.

The bracket is designed to use minimal upright space, so other attachments can still sit close by.

UHMW wear pads are fitted to the bracket where it contacts the upright, protecting your rack's finish — don't remove them.

No fixing bolts are supplied with this attachment — the built-in quick-release pin is the only fitting hardware.

Need help? Contact support@vervefitness.com or visit vervefitness.com/support

What's in the Box.

Check the items below before fitting. If anything is missing or damaged, contact VERVE support before you start.

- **2× Plate Storage Horns** — each a horn, mounting bracket and quick-release pin, welded and finished as one pre-assembled unit
- **UHMW wear pads** — pre-fitted to each bracket where it contacts the upright
- **Built-in mounting hardware** — a quick-release pin is part of each bracket itself; no separate bolts, spacers or brackets are supplied



One horn assembly, as shipped — horn, bracket and quick-release pin in one welded unit

NOTE

The source documentation for this attachment does not give the upright hole spacing, pin dimensions or a load rating. If you are fitting these to anything other than a current VERVE rack or rig, confirm fit and suitability before installing, or contact VERVE support for the specifics of your equipment.

Fitting & Use.

Each bracket carries a quick-release pin that lines up with your upright's existing hole pattern — the same holes used by your other rack and rig attachments.

To fit each horn:

- Decide the height you want the horn at, using your upright's numbered hole pattern as a reference.
- Bring the bracket up to the upright so it sits flush against the face, with the pin aligned to your chosen hole.
- Push the pin fully through the hole until the bracket is drawn flush and square against the upright.
- Pull down firmly on the horn to confirm the bracket is fully seated and the pin is engaged before loading any plates.
- Repeat for the second horn, at the same height for a level pair or a different height to separate plate sizes.



Bracket detail — quick-release pin against the upright's numbered holes

To use it:

Slide plates onto the horn from the open end and push them back against the bracket. Load plates evenly across both horns rather than stacking them all on one side. To remove or reposition a horn, withdraw the pin, lift the bracket clear of the upright, and refit at the new hole following the steps above.

Final Checks.

- ☐ Each quick-release pin is fully through the upright hole and its bracket sits flush before loading either horn.
- ☐ Both horns are mounted at a height and spacing that suits the plates you're storing.
- ☐ Plates are loaded evenly across both horns, not stacked entirely on one side.
- ☐ Neither horn lifts, twists or drops off the upright when pulled down or knocked sideways.
- ☐ Re-check pin engagement before every session and after refitting a horn.



NEED HELP?

Missing parts, damaged components or fitting questions — we'll sort it fast.

Contact support@vervefitness.com or visit vervefitness.com/support